

AQUALISA

ilux[®]

Digital

Remote controls

Pre Summer 2007



Remote controls

ilux Digital Shower remote control



ilux Digital
Shower remote
control
ILDSRC

ilux Digital Bath remote control



ilux Digital
Bath remote
control
ILDBRC

Components

Shower remote control



Literature not shown

Bath remote control



Literature not shown

Important information

ilux Digital remote controls are wireless and fully mobile and provide a secondary method of Start/Stop and pre-set functions to the ilux Digital product controllers. The ilux Digital bath remote control also provides an additional Hot Top Up button, which allows a bather to top up the bath with maximum temperature water at minimum flow rate without using the bath controller.

Ilux Digital remote controls can operate from up to 10m from the Digital controllers.

The remote controls are fully waterproof, though full submersion in water should be avoided.

THIS PRODUCT MUST BE INSTALLED BY A COMPETENT PERSON IN ACCORDANCE WITH ALL RELEVANT CURRENT WATER AND ELECTRICAL SUPPLY REGULATIONS.

This product is suitable for domestic use only.

This product is supplied complete with a 5 year guarantee. The battery is not covered by the terms of guarantee. A replacement CR2032 battery is available from Aqualisa customer service, part number 489501. Any product problems that may arise if any other replacement battery is used will not be covered by our terms of guarantee.

Please refer to the separate ilux user guide for full operating and cleaning instructions.

Step-by-step instructions



In addition to the guide below it is essential that the written instructions below are read and understood and that you have all the necessary components (shown below) before commencing installation. Failure to install the product in accordance with these instructions may adversely affect the warranty terms and conditions. Do not undertake any part of this installation unless you are competent to do so. Prior to starting, ensure that you are familiar with the necessary plumbing regulations required to install the product correctly and safely.

ilux Digital remote controls are supplied with universal fittings intended to secure the control to a suitable wall.

1

Using the cradle as template, mark the fixing points in the desired location.



2

Drill and prepare the fixing points using the fixings supplied, if suitable.

3

Secure the cradle to the wall using the screws provided, if suitable.



4

Using a small posidrive screwdriver, carefully undo the fixing screw and remove the battery cover.



5

Place the CR2032 battery, positive side facing up, into the rear of the remote control.



6

Ensuring the battery seal is in the correct position to create a water tight seal, replace the battery cover and secure using the fixing screw.



!

Incorrect fitting of the battery seal will mean the remote control is no longer waterproof. Any product problems arising from incorrect battery fitting or replacement will not be covered by our terms of guarantee.

7

Place the remote control into the cradle.



Commissioning

!

After installation of the shower/bath system has been completed and the remote control has been assembled, the remote control will need to be paired with the shower or bath controller adopting the procedure detailed below.

1

Ensure the Digital controller is connected to the Digital processor.

2

Ensure the Digital processor is connected to the main power supply and the controller is turned off.

3

Press and hold the remote control Start/Stop button simultaneously with the Digital controller Pause button (ilux Digital Shower) or Lock button (ilux Digital Bath) for four seconds to activate the remote control.

Commissioning ilux Digital Shower



Commissioning ilux Digital Bath



The remote control will beep three times to indicate the remote control is now active.

4

Place the remote control into the cradle.

Changing the battery


!

A replacement CR2032 battery is available from Aqualisa customer service on 01959 560010, part number 489501. Any product problems that may arise if any other replacement battery is used will not be covered by our terms of guarantee.

The exhausted battery should not be disposed of in municipal waste. Use a battery disposal facility. Please check local waste regulations.

1

Using a small posidrive screwdriver, carefully undo the fixing screw and remove the battery cover.



3

Ensuring the battery seal is in the correction position to create a water tight seal, replace the battery cover and secure using the fixing screw.



Incorrect fitting of the battery seal will mean the remote control is no longer waterproof. Any product problems arising from incorrect battery replacement will not be covered by our terms of guarantee.



AQUALISA

Aqualisa Products Limited
The Flyer's Way
Westerham Kent TN16 1DE

Sales enquiries: 01959 560010
Republic of Ireland 01-864-3363

Customer helpline: 01959 560010
Republic of Ireland 01-844-3212

Brochure Hotline: 0800 652 3669
Website: www.aqualisa.co.uk
Email: enquiries@aqualisa.co.uk

Please note that calls may be recorded for training and quality purposes
The company reserves the right to alter, change or modify the product specifications without prior warning

® Registered Trademark Aqualisa Products Limited